

## Oasis Spillover Instructions (Plumbed with 2" Lines)

For the square Oasis spill over a majority of dealers/installers do not want the air control on the top of the vessel. Most installations today have decorative stone on the top. Instructions below on how to complete the final air control installation along with additional plumbing instructions.

REMEMBER, always fill the vessel for 24 hours before you pour your deck to ensure no plumbing leaks during transit and installation!



### Plumbing instructions

- One blue line runs to pool pump suction side
- The unmarked white line runs from the pool pump return side
- One blue line runs to booster pump suction side
- Red line is return line from booster pump.

1



There are two air manifolds on the vessel. Once you decide where you want to have the air control located drill 1 1/4" hole in the side flange of the vessel.

REMEMBER the air line must be above the water line of the vessel.  
REMEMBER there are two manifolds and air controls.

2



Glue elbow supplied.  
Aim in direction of the hole you drilled.  
Use Heavy Duty Clear PVC cement.

3



Slide pipe through previously cut hole (Drilled hole not shown) and glue the pipe supplied into the elbow. Run the line to your selected location.

4



Glue pipe into air control at final location for access from inside the tub and REMEMBER must be above the water line of the vessel.

Example

Red arrow to show suggested location above vessel water line on the side of stone paver.



Question please call or text 404.661.2283